

Existing Item no / SKU	Product Name	Product Description		New item no / SKU	Product Name
50-2119	Jabra Engage 50 II Link	USB-A, MS		50-2169	Jabra Engage 50 II Link, USB C/A, MS
50-2159	Jabra Engage 50 II Link	USB-C, MS			
50-2219	Jabra Engage 50 II Link	USB-A, UC		50-2269	Jabra Engage 50 II Link, USB C/A, UC
50-2259	Jabra Engage 50 II Link	USB-C, UC			
5093-299-2119	Jabra Engage 50 II	50 II Link, Mono, USB-A, MS		5093-299-2169	Jabra Engage 50 II, Link, Mono,USB C/A, MS
5093-299-2159	Jabra Engage 50 II	50 II Link, Mono, USB-C, MS			
5093-299-2219	Jabra Engage 50 II	50 II Link, Mono, USB-A, UC		5093-299-2269	Jabra Engage 50 II, Link, Mono,USB C/A, UC
5093-299-2259	Jabra Engage 50 II	50 II Link, Mono, USB-C, UC			
5099-299-2119	Jabra Engage 50 II	50 II Link, Stereo, USB-A, MS		5099-299-2169	Jabra Engage 50 II, Link, Stereo,USB C/A, MS
5099-299-2159	Jabra Engage 50 II	50 II Link, Stereo, USB-C, MS			
5099-299-2219	Jabra Engage 50 II	50 II Link, Stereo, USB-A, UC		5099-299-2269	Jabra Engage 50 II, Link, Stereo,USB C/A, UC
5099-299-2259	Jabra Engage 50 II	50 II Link, Stereo, USB-C, UC			
4093-413-279	Jabra Engage 40	Inline Link, Mono, USB-A, MS		4093-413-269	Jabra Engage 40, Inline Link, Mono, USB C/A, MS
4093-413-299	Jabra Engage 40	Inline Link, Mono, USB-C, MS			
4093-419-279	Jabra Engage 40	Inline Link, Mono, USB-A, UC		4093-419-269	Jabra Engage 40, Inline Link, Mono, USB C/A, UC
4093-419-299	Jabra Engage 40	Inline Link, Mono, USB-C, UC			
4099-413-279	Jabra Engage 40	Inline Link, Stereo, USB-A, MS		4099-413-269	Jabra Engage 40, Inline Link, Stereo, USB C/A, MS
4099-413-299	Jabra Engage 40	Inline Link, Stereo, USB-C, MS			
4099-419-279	Jabra Engage 40	Inline Link, Stereo, USB-A, UC		4099-419-269	Jabra Engage 40, Inline Link, Stereo, USB C/A, UC
4099-419-299	Jabra Engage 40	Inline Link, Stereo, USB-C, UC			
23189-999-979	Jabra Evolve2 30 SE	Stereo USB-A, MS		23189-999-779	Jabra Evolve2 30 SE, MS Stereo USB C/A
23189-999-879	Jabra Evolve2 30 SE	Stereo USB-C, MS			
23189-989-879	Jabra Evolve2 30 SE	Stereo USB-C, UC		23189-989-779	Jabra Evolve2 30 SE, UC Stereo USB C/A
23189-989-979	Jabra Evolve2 30 SE	Stereo USB-A, UC			

23189-899-979	Jabra Evolve2 30 SE	Mono USB-A, MS		23189-899-779	Jabra Evolve2 30 SE, USB C/A, MS Mono
23189-899-879	Jabra Evolve2 30 SE	Mono USB-C, MS			
23189-889-979	Jabra Evolve2 30 SE	Mono USB-A, UC		23189-889-779	Jabra Evolve2 30 SE, USB C/A, UC Mono
23189-889-879	Jabra Evolve2 30 SE	Mono USB-C, UC			
25089-989-999	Jabra Evolve2 50	USB-A UC Stereo		25089-989-799	Jabra Evolve2 50, USB C/A UC Stereo
25089-989-899	Jabra Evolve2 50	USB-C UC Stereo			
25089-999-999	Jabra Evolve2 50	USB-A MS Stereo		25089-999-799	Jabra Evolve2 50, USB C/A MS Stereo
25089-999-899	Jabra Evolve2 50	USB-C MS Stereo			
25089-889-999	Jabra Evolve2 50	USB-A UC Mono		25089-889-799	Jabra Evolve2 50, USB C/A UC Mono
25089-889-899	Jabra Evolve2 50	USB-C UC Mono			
25089-899-999	Jabra Evolve2 50	USB-A MS Mono		25089-899-799	Jabra Evolve2 50, USB C/A MS Mono
25089-899-899	Jabra Evolve2 50	USB-C MS Mono			
4999-829-209	Jabra Evolve 20	USB-A, UC Stereo		4999-829-269	Jabra Evolve 20, USB C/A, UC Stereo
4999-829-289	Jabra Evolve 20	USB-C, UC Stereo			
4999-823-109	Jabra Evolve 20	USB-A, MS Stereo		4999-823-169	Jabra Evolve 20, USB C/A, MS Stereo
4999-823-189	Jabra Evolve 20	USB-C, MS Stereo			
4993-823-109	Jabra Evolve 20	USB-A, MS Mono		4993-823-169	Jabra Evolve 20, USB C/A MS Mono
4993-823-189	Jabra Evolve 20	USB-C, MS Mono			
4993-829-289	Jabra Evolve 20	USB-C, UC Mono		4993-829-269	Jabra Evolve 20, USB C/A UC Mono
4993-829-209	Jabra Evolve 20	USB-A, UC Mono			
4993-823-309	Jabra Evolve 20 SE	USB-A, MS Mono		4993-823-369	Jabra Evolve 20 SE, USB C/A, MS Mono
4993-823-389	Jabra Evolve 20 SE	USB-C, MS Mono			
4993-829-409	Jabra Evolve 20 SE	USB-A, UC Mono		4993-829-469	Jabra Evolve 20 SE, USB C/A, UC Mono
4993-829-489	Jabra Evolve 20 SE	USB-C, UC Mono			
4999-823-309	Jabra Evolve 20 SE	USB-A, MS Stereo		4999-823-369	Jabra Evolve 20 SE, USB C/A, MS Stereo
4999-823-389	Jabra Evolve 20 SE	USB-C, MS Stereo			
4999-829-409	Jabra Evolve 20 SE	USB-A, Stereo UC		4999-829-469	Jabra Evolve 20 SE, USB C/A, UC Stereo
4999-829-489	Jabra Evolve 20 SE	USB-C, Stereo UC			
5393-823-309	Jabra Evolve 30 II	USB-A Mono MS		5393-823-369	Jabra Evolve 30 II, USB C/A Mono MS

5393-823-389	Jabra Evolve 30 II	USB-C Mono MS	→	5393-823-369	Jabra Evolve 30 II, USB C/A Mono MS
5393-829-309	Jabra Evolve 30 II	USB-A Mono UC	→	5393-829-369	Jabra Evolve 30 II, USB C/A Mono UC
5393-829-389	Jabra Evolve 30 II	USB-C Mono UC			
5399-823-309	Jabra Evolve 30 II	USB-A Stereo MS	→	5399-823-369	Jabra Evolve 30 II, USB C/A Stereo Stereo MS
5399-823-389	Jabra Evolve 30 II	USB-C Stereo MS			
5399-829-309	Jabra Evolve 30 II	USB-A Stereo UC	→	5399-829-369	Jabra Evolve 30 II, USB C/A Stereo Stereo UC
5399-829-389	Jabra Evolve 30 II	USB-C Stereo UC			